

Operation

CALL LOG

1. Press the 3-Way button once to enter the Call Log menu. The three call log categories are: Missed Calls -> Dialed Calls -> Received Calls in that order.
2. Move the 3-Way button to the LEFT or RIGHT to navigate the three logs.
3. Press the 3-Way button once to enter the each log.
4. After you enter a Call Log, move the 3-Way button to the LEFT or RIGHT to navigate through the phone numbers. Press the Multi-Function Button to call the highlighted phone number.
5. Press the Cancel Button to quit the Call Log.

CALL LOG DISPLAY

Within the Call Logs, each number is preceded by a space to designate the order of the calls.

The first screen will show the first eleven digits of the logged number. E.g. The number " 07753373877 " is displayed as follows: 07753373877

RECONNECT TO CELL

1. If the BN607 loses connection by moving out of operating distance of the paired cell phone, reconnect by moving it within the operating area and press the Multi-Function button once to reconnect to the cell phone.
2. If the BN607 is disconnected because of being powered off, it will connect automatically after powering on again.

STORAGE CONDITIONS

Operating Temperature Range: 0°C to +50°C without loss of function
Storage Temperature Range: -20°C to +65°C without any damage to the BN 607
Humidity Range: 30%–90% humidity @ +60°C without loss of function

EARBUD

Insert the earbud's plug into the headphone jack on the side of the BN607.
Use the Earbud for privacy or high ambient noise situations.

In order to get the excellent effect, please lift up "LCD Screen" to 30 degree.

*Note: Please refer to your cell phone's product user manual for Voice Dialing, Call & Redial functionality and settings.

ICONS



When the BN607 completes a Bluetooth® connection, the Bluetooth® icon will be on.



A solid Battery Power Level icon will display when the battery is full; One line on Battery Power Level icon will display when the battery is half full; only the battery frame will remain when the battery is discharged.



When opening the Call Logs, the Phonebook icon will be on.



When entering the Received Call Log, the Received Call icon on the LCD and the Phonebook icon will be on.



When there is an incoming call, the Incoming Call icon will be on while the backlit LCD flashes



The Missed Call icon will be on when a call is missed and until that call is acknowledged.



When entering the Dialed phone numbers in the Phonebook, the Outgoing Call icon on the LCD and the Phonebook icon will be on.



When checking a phone number in the Missed Call Log, the Missed Call icon and the Phonebook icon will be on.



Caution:The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Notes:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These Limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warranty

Hayat and Hu Corporation Ltd provides one year manufacturer warranty to this product.

If you need support for this product, you can find FAQs from www.bluenext.co.uk

Or contact the technical support

Email: info@bluenext.co.uk

Address: Technical Support Centre

Hayat and Hu Corporation Ltd
Manchester Technology Centre
Armstrong House
Oxford Road
Manchester
M1 7ED

Tel: 0161 228 6363